CB-WX-M Airmar Weather Sensor Mount Quick Start Guide


The NexSens CB-WX-M is designed to mount an Airmar WX-Series weather sensor to a CB-Series data buoy.



Install the Extension Arm

Note: The following guide applies to CB-150 and CB-450 model buoys.

- 1 Use a 9/16" socket to remove the white top plate from the buoy's solar tower.
- Run the ¾" bolt, lock-washer, and washer from the extension arm through a vacant mounting hole on the plate. Thread the bolt into the arm's base.



3 Tighten the arm to the plate using a ¾" socket or hex driver.





CB-WX-M Airmar Weather Sensor Mount Quick Start Guide

Install the Airmar Weather Station

1 Thread the cable guide coupler from the Airmar onto the extension arm.





2 Feed the sensor cable assembly through the coupler and tighten it together.





Connect the sensor cable to the Airmar, then tighten the threaded collar onto the station.





Route, armor and zip tie the sensor cable so that it is protected from abrading. Re-install the tower plate onto the buoy.



